


P1


P2

PAG	POS	REFERENCIA	DESCRIPCION	CANT
P1	1	GY5000TL/M	MOTOR GY5000TL	1
P1	2	GY5000TL/P1/2	TAPON GY5000TL	2
P1	3	GY5000TL/P1/3	PARAGOLPES GY5000TL	1
P1	4	GY5000TL/P1/4	TUERCA 8 GY5000TL	4
P1	5	GY5000TL/P1/5	ARANDELA ELASTICA 8 GY5000TL	8
P1	6	GY5000TL/P1/6	ARANDELA PLANA GY5000TL	4
P1	7	GY5000TL/P1/7	TORNILLO 8X45 GY5000TL	4
P1	8	GY5000TL/P1/8	TORNILLO 10X40 GY5000TL	2
P1	9	GY5000TL/P1/9	SOPORTE PARAGOLPES GY5000TL	1
P1	10	GY5000TL/P1/10	ARANDELA ELASTICA 10 GY5000TL	2
P1	11	GY5000TL/P1/11	TUERCA 10 GY5000TL	2
P1	12	GY5000TL/P1/12	JUNTA CAJA-MOTOR GY5000TL	1
P1	13	GY5000TL/P1/13	PASADOR 2,5X30 GY5000TL	1
P1	14	GY5000TL/P1/14	TORNILLO TAPON RESPIRADERO GY5000TL	1
P1	15	GY5000TL/P1/15	SOPORTE CAJA GY5000TL	1
P1	16	GY5000TL/P1/16	TORNILLO 8X25 GY5000TL	4
P1	17	GY5000TL/P1/17	JUNTA CIERRE CAJA GY5000TL	1
P1	18	GY5000TL/P1/18	TORNILLO 10 GY5000TL	4
P1	19	GY5000TL/T	TRANSMISION GY5000TL	1

PAG	POS	REFERENCIA	DESCRIPCION	CANT
P2	1	GY5000TL/P2/1	TORNILLO 10X30 GY5000TL	1
P2	2	GY5000TL/P2/2	TUERCA 10 GY5000TL	1
P2	3	GY5000TL/P2/3	PALANCA CAMBIO INFERIOR GY5000TL	1
P2	4	GY5000TL/P2/4	TORNILLO 10X140 GY5000TL	1
P2	5	GY5000TL/P2/5	CABLE ACELERADOR GY5000TL	1
P2	6	GY5000TL/P2/6	CABLE MARCHA ATRAS GY5000TL	1
P2	7	GY5000TL/P2/7	SUJETA CABLE GY5000TL	4
P2	8	GY5000TL/P2/8	POMO PALANCA GY5000TL	2
P2	9	GY5000TL/P2/9	PALANCA CAMBIO GY5000TL	1
P2	10	GY5000TL/P2/10	GRUPILLA 9 GY5000TL	1
P2	11	GY5000TL/P2/11	PASADOR R GY5000TL	1
P2	12	GY5000TL/P2/12	CAJA HERRAMIENTAS GY5000TL	1
P2	13	GY5000TL/P2/13	MANDO ACELERADOR GY5000TL	1
P2	14	GY5000TL/P2/14	PUÑO GY5000TL	2
P2	15	GY5000TL/P2/15	MANETA PARE CON CABLE GY5000TL	1
P2	16	GY5000TL/P2/16	POMO EMBRAGUE M.ATRAS GY5000TL	2
P2	17	GY5000TL/P2/17	PASADOR 1,6X20 GY5000TL	4
P2	18	GY5000TL/P2/18	PASADOR 7X24 GY5000TL	2
P2	19	GY5000TL/P2/19	PASADOR 10X24 GY5000TL	2
P2	20	GY5000TL/P2/20	TORNILLO 6X12 GY5000TL	4
P2	21	GY5000TL/P2/21	TUERCA 6 GY5000TL	4
P2	22	GY5000TL/P2/22	MANILLAR SUPERIOR GY5000TL	1
P2	23	GY5000TL/P2/23	CABLE EMBRAGUE GY5000TL	1
P2	24	GY5000TL/P2/24	POMO AJUSTE MANILLAR GY5000TL	1
P2	25	GY5000TL/P2/25	SOPORTE MANILLAR GY5000TL	1
P2	26	GY5000TL/P2/26	TORNILLO 10X30 GY5000TL	4
P2	27	GY5000TL/P1/10	ARANDELA ELASTICA 10 GY5000TL	4





P3



P4

PAG	POS	REFERENCIA	DESCRIPCION	CANT
P3	1	GY5000TL/P3/1	TORNILLO 10X50 GY5000TL	3
P3	2	GY5000TL/P3/2	SOPORTE ENGANCHE GY5000TL	1
P3	3	GY5000TL/P1/11	TUERCA 10 GY5000TL	5
P3	4	GY5000TL/P3/4	PASADOR 8S43 GY5000TL	1
P3	5	GY5000TL/P3/5	BULON GY5000TL	1
P3	6	GY5000TL/P1/10	ARANDELA ELASTICA 10 GY5000TL	3
P3	7	GY5000TL/P3/7	PASADOR R GY5000TL	2
P3	8	GY5000TL/P3/8	ENGANCHE GY5000TL	1
P3	9	GY5000TL/P2/1	TORNILLO 10X30 GY5000TL	2
P3	10	GY5000TL/P3/10	BARRA PROFUNDIDAD GY5000TL	1
PAG	POS	REFERENCIA	DESCRIPCION	CANT
P4	1	GY5000TL/P4/1	TUERCA 10 GY5000TL	4
P4	2	GY5000TL/P2/21	TUERCA 8 GY5000TL	8
P4	3	GY5000TL/P4/3	SOPORTE DELANTERO GY5000TL	2
P4	4	GY5000TL/P4/4	ARANDELA 6 GY5000TL	8
P4	5	GY5000TL/P4/5	TORNILLO 6X16 GY5000TL	8
P4	6	GY5000TL/P4/6	ALETA GUARDABARROS DRCH GY5000TL	1
P4	7	GY5000TL/P4/7	TORNILLO 10X20 GY5000TL	4
P4	8	GY5000TL/P4/8	SOPORTE TRASERO GY5000TL	1
P4	9	GY5000TL/P4/9	ALETA GUARDABARROS IZQ GY5000TL	1


P5



P6

PAG	POS	REFERENCIA	DESCRIPCION	CANT
P5	1	GY5000TL/P5/1	DISCO LATERAL GY5000TL	1
P5	2	GY5000TL/P5/2	PASADOR GY5000TL	1
P5	3	GY5000TL/P3/4	PASADOR 8X43 GY5000TL	1
P5	4	GY5000TL/P5/4	PORTACUCHILLAS EXT GY5000TL	1
P5	5	GY5000TL/P1/7	TORNILLO 8X40 GY5000TL	1
P5	6	GY5000TL/P5/6	TORNILLO 10X35 GY5000TL	12
P5	7	GY5000TL/P5/7	CUCHILLA DERECHA GY5000TL	6
P5	8	GY5000TL/P5/8	CUHILLA IZQUIERDA GY5000TL	6
P5	9	GY5000TL/P1/11	TUERCA 10 GY5000TL	12
P5	10	GY5000TL/P1/10	ARANDELA ELASTICA 10 GY5000TL	12
P5	11	GY5000TL/P1/5	ARANDELA ELASTICA 8 GY5000TL	1
P5	12	GY5000TL/P1/4	TUERCA 8 GY5000TL	1
P5	13	GY5000TL/P5/13	PORTACUCHILLAS INT GY5000TL	1
PAG	POS	REFERENCIA	DESCRIPCION	CANT
P6	1	GY5000TL/P6/1	TORNILLO 8X22 GY5000TL	5
P6	2	GY5000TL/P6/2	LLANTA EXT GY5000TL	1
P6	3	GY5000TL/P6/3	CUBIERTA 4,00-8 GY5000TL	1
P6	4	GY5000TL/P6/4	CAMARA 4,00-8 GY5000TL	1
P6	5	GY5000TL/P6/5	LLANTA INT GY5000TL	1
P6	6	GY5000TL/P1/5	ARANDELA ELASTICA 8 GY5000TL	5
P6	7	GY5000TL/P6/7	EJE RUEDA GY5000TL	1
P6	8	GY5000TL/P6/8	TUERCA 8 GY5000TL	5
P6	9	GY5000TL/P3/4	PASADOR 8X43 GY5000TL	1
P6	10	GY5000TL/P6/10	CLIP PASADOR GY5000TL	1

P7



PAG	POS	REFERENCIA	DESCRIPCION	CANT	PAG	POS	REFERENCIA	DESCRIPCION	CANT	PAG	POS	REFERENCIA	DESCRIPCION	CANT
P7	1	GY5000TL/P7/1	PROTECTOR RETEN GY5000TL	2	P7	31	GY5000TL/P7/31	ARANDELA AJUSTE GY5000TL	1	P7	61	GY5000TL/P7/61	ENGRANAJE GY5000TL	1
P7	2	GY5000TL/P7/2	RETEN 25X47X7 GY5000TL	4	P7	32	GY5000TL/P7/32	TAPON 40X10 GY5000TL	1	P7	62	GY5000TL/P7/62	BOLA 6,35 GY5000TL	4
P7	3	GY5000TL/P7/3	ARANDELA VACIADO GY5000TL	1	P7	33	GY5000TL/P7/33	GRUPILLA 40 GY5000TL	1	P7	63	GY5000TL/P7/63	MUELLE BOLA GY5000TL	2
P7	4	GY5000TL/P7/4	TAPON VACIADO GY5000TL	1	P7	34	GY5000TL/P7/34	RETEN 20X40X7 GY5000TL	1	P7	64	GY5000TL/P7/64	EJE PRINCIPAL GY5000TL	1
P7	5	GY5000TL/P7/5	CAJA TRACCION INFERIOR GY5000TL	1	P7	35	GY5000TL/P7/35	TAPA PROTECTORA GY5000TL	1	P7	65	GY5000TL/P7/65	GRUPILLA 20 GY5000TL	2
P7	6	GY5000TL/P7/6	RODAMIENTO 6305 GY5000TL	1	P7	36	GY5000TL/P7/36	TORNILLO 6X12 GY5000TL	4	P7	66	GY5000TL/P7/66	EMBRAGUE GY5000TL	1
P7	7	GY5000TL/P7/7	CASQUILLO 26,5X34X37 GY5000TL	1	P7	37	GY5000TL/P7/37	TORNILLO 10X25 GY5000TL	1	P7	67	GY5000TL/P7/67	ARANDELA EMBRAGUE GY5000TL	1
P7	8	GY5000TL/P7/8	EJE HEXAGONAL GY5000TL	1	P7	38	GY5000TL/P7/38	ARANDELA 10 GY5000TL	1	P7	68	GY5000TL/P7/68	RODAMIENTO 6202 GY5000TL	1
P7	9	GY5000TL/P7/9	PIÑON EJE HEXAGONAL GY5000TL	1	P7	39	GY5000TL/P7/39	PASADOR 5X10 GY5000TL	1	P7	69	GY5000TL/P7/69	TORNILLO 6X16 GY5000TL	2
P7	10	GY5000TL/P7/10	RODAMIENTO 30305 GY5000TL	1	P7	40	GY5000TL/P7/40	TORICA 18X1,8 GY5000TL	1	P7	70	GY5000TL/P7/70	ARANDELA DENTADA 6 GY5000TL	1
P7	11	GY5000TL/P7/11	JUNTA TAPA GY5000TL	1	P7	41	GY5000TL/P7/41	EJE REVERSA GY5000TL	1	P7	71	GY5000TL/P7/71	ARANDELA PLANA 6 GY5000TL	1
P7	12	GY5000TL/P7/12	TAPA EJE HEXAGONAL GY5000TL	1	P7	42	GY5000TL/P7/42	PLACA EMPUJE REVERSA GY5000TL	1	P7	72	GY5000TL/P1/14	TORNILLO TAPON RESPIRADERO GY5000TL	1
P7	13	GY5000TL/P7/13	ARANDELA 8 GY5000TL	13	P7	43	GY5000TL/P7/43	ENGRANAJE DOBLE REVERSA GY5000TL	1	P7	73	GY5000TL/P1/12	JUNTA CAJA-MOTOR GY5000TL	1
P7	14	GY5000TL/P1/5	ARANDELA ELASTICA 8 GY5000TL	17	P7	44	GY5000TL/P7/44	ASIENTO RESORTE GY5000TL	1	P7	74	GY5000TL/P1/15	SOPORTE CAJA GY5000TL	1
P7	15	GY5000TL/P7/15	TORNILLO 8X30 GY5000TL	6	P7	45	GY5000TL/P7/45	RESORTE GY5000TL	1	P7	75	GY5000TL/P7/75	TORNILLO 8X25 GY5000TL	4
P7	16	GY5000TL/P7/16	EJE GY5000TL	1	P7	46	GY5000TL/P7/46	TAPA LIMITADOR GY5000TL	1	P7	76	GY5000TL/P7/76	RODAMIENTO 6007 GY5000TL	1
P7	17	GY5000TL/P7/17	RODAMIENTO 30204 GY5000TL	1	P7	47	GY5000TL/P7/47	TUERCA 12 GY5000TL	1	P7	77	GY5000TL/P7/77	CARCASA EMBRAGUE GY5000TL	1
P7	18	GY5000TL/P7/18	RODAMIENTO 30205 GY5000TL	1	P7	48	GY5000TL/P7/48	TORICA 10X2 GY5000TL	8	P7	78	GY5000TL/P1/17	JUNTA CIERRE CAJA GY5000TL	1
P7	19	GY5000TL/P7/19	ENGRANAJE SUPERIOR GY5000TL	1	P7	49	GY5000TL/P7/49	PALANCA REVERSA GY5000TL	1	P7	79	GY5000TL/P7/79	TORNILLO 8X40 GY5000TL	4
P7	20	GY5000TL/P7/20	ARANDELA 12 GY5000TL	1	P7	50	GY5000TL/P7/50	HORQUILLA CAMBIO REVERSA GY5000TL	1	P7	80	GY5000TL/P7/80	CENTRADOR GY5000TL	2
P7	21	GY5000TL/P7/21	ARANDELA ELASTICA 12 GY5000TL	1	P7	51	GY5000TL/P7/51	TORNILLO 5X25 GY5000TL		P7	81	GY5000TL/P2/2	TUERCA GY5000TL	1
P7	22	GY5000TL/P7/22	TUERCA 12 GY5000TL	1	P7	52	GY5000TL/P7/52	ASIENTO CABLE GY5000TL	1	P7	82	GY5000TL/P7/82	BRAZO CAMBIO GY5000TL	1
P7	23	GY5000TL/P1/8	TORNILLO 10X40 GY5000TL	4	P7	53	GY5000TL/P6/8	TUERCA 8 GY5000TL	1	P7	83	GY5000TL/P7/83	CASQUILLO 14X18X26 GY5000TL	4
P7	24	GY5000TL/P7/24	ARANDELA ELASTICA 10 GY5000TL	6	P7	54	GY5000TL/P7/54	TOPE CABLE EMBRAGUE GY5000TL	1	P7	84	GY5000TL/P7/84	PASADOR 2C25 GY5000TL	1
P7	25	GY5000TL/P7/25	JUNTA UNION GY5000TL	1	P7	55	GY5000TL/P7/55	PALANCA EMBRAGUE GY5000TL	1	P7	85	GY5000TL/P7/85	EJE HORQUILLA CAMBIO GY5000TL	1
P7	26	GY5000TL/P1/11	TUERCA 10 GY5000TL	4	P7	56	GY5000TL/P7/56	PASADOR 6X25 GY5000TL	1	P7	86	GY5000TL/P7/86	HORQUILLA CAMBIO GY5000TL	1
P7	27	GY5000TL/P7/27	CHAVETA 6X6X20 GY5000TL	1	P7	57	GY5000TL/P7/57	PASADOR ALETA 1,6X16 GY5000TL	1	P7	87	GY5000TL/P7/87	VARILLA NIVEL ACEITE GY5000TL	1
P7	28	GY5000TL/P7/28	EJE GY5000TL	1	P7	58	GY5000TL/P7/58	HORQUILLA EMBRAGUE GY5000TL	1	P7	88	GY5000TL/P7/88	ARANDELA 17 GY5000TL	2
P7	29	GY5000TL/P7/29	ENGRANAJE DOBLE GY5000TL	1	P7	59	GY5000TL/P7/59	GRUPILLA 14 GY5000TL	1					